Organoid® RELAX on flax backing **Product** Name Article number RLX0000085FVPRW **Producer** ORGANOID® TECHNOLOGIES GMBH Address Nesselgarten 422 / Top 5 A-6500 Fließ Austria **Description and** Name Organoid® RELAX on flax backing applications Description Natural plant material in full coverage on natural non-woven flax backing produced climate neutral in Tyrol **Applications** As wallpaper As a compound in wood-working Plant material and Plant material Soothing herbal mixture density Density Premium density, full coverage Rolled goods, width 1 360 mm Size and weight Size Thickness 0.8 mm Weight 720 g/m<sup>2</sup> **Product requirements** Binding agent safe for usage in contact with Food-safety food in accordance with EU-regulation 1935/2004 **Backing material** Material Natural, non-woven flax fleece **Properties** Unbleached and breathable from a renewable material Contains 100% flax Certified OEKO-TEX 100 Tensile strength in accordance with ISO9073-3: MD N/5cm 65 CD N/5cm 45 **Technical** Cut Use scissors, a cutter or a plotter implementation **Edges** Allow for imperfections 1-2 mm around the edges How to install As wallpaper: • Wall-pasting technique: Apply glue directly on the wall, apply wallpaper vertically and press on using a rubber roller • Double cut: Each panel overlaps with the

one next to it (approx. 2 cm)Free match: The naturally scattered

between panels

materials do not require matching patterns

## As a compound in wood-working

- Process with normal wood-working machinery
- Glue (e.g. white glue) is applied onto the wooden materials, as the fleece absorbs moisture and glue stains may appear on the front if glue is applied to the fleece
- Cover the natural surface with the enclosed separating paper
- uidelines:

Max. pressing temperature. 60°C Max. pressure 1 kg/cm<sup>2</sup>

Glue application: approx. 100 g/m<sup>2</sup> Pressing time: approx. 15 minutes

Pre-trials and tests are recommended

Glue recommendations

As wallpaper: Glutolin ECC extra clear As a compound in wood-working: White glue

Pay attention to

Surface must be clean, dry, weight-bearing, evenly absorbent, smooth, dust-free and neutral in colour. Recently plastered walls must be fully dried. Highly absorbent walls must be prepared with a suitable base.

For sensitive wood-working applications, use a counter-balance (enclosed on request). Symmetrical construction is recommended, which means using the same surface on the front and back side.

Acclimatisation of Organoid natural surfaces:

- Bring product to room temperature before unpacking
- Store product protected from light, at about 20°C and 30-60 % relative humidity.

## Storage:

- Rolled goods: hanging system (e.g. paternoster)
- Single panels: horizontal position (e.g. drawer system)

Processing guidelines available at:

www.organoids.com/en/installation-technical-implementation