Product Name Organoid® WILDSPITZE on flax backing Article number WSP0000075FVPRW **Producer** Address ORGANOID TECHNOLOGIES GMBH Nesselgarten 422 / Top 5 A-6500 Fließ Austria **Description and** Name Organoid® WILDSPITZE on flax backing applications Description Natural plant material in full coverage on natural non-woven flax backing produced climate neutral in Tyrol **Applications** As wallpaper As a compound in wood-working Plant material and Plant material Regional, hand-cut Alpine hay from the density Tyrolean Alps Density Premium density, full coverage Size and weight Rolled goods, width 1 360 mm Size Thickness 1.0 mm Weight 520 g/m² **Product requirements** Hardly inflammable C-s1, d0 in accordance with EN ISO 13501-01 Concentration of allergens in decorative layer Hypoallergenic below detectable amount: < 0,08 (µg/g) Food-safety Binding agent safe for usage in contact with food in accordance with EU-regulation 1935/2004 **Backing material** Material Natural, non-woven flax fleece **Properties** Unbleached and breathable from a renewable material Contains 100% flax Certified OEKO-TEX 100 Tensile strength in accordance with ISO9073-3: MD N/5cm 65 CD N/5cm 45 **Technical** Cut Use scissors, a cutter or a plotter implementation Edges Allow for imperfections 1-2 mm around the edges How to install As wallpaper: Wall-pasting technique: Apply glue directly on the wall, apply wallpaper vertically and press on using a rubber roller

• Double cut: Each panel overlaps with the

one next to it (approx. 2 cm)Free match: The naturally scattered

materials do not require matching patterns between panels

As a compound in wood-working

- Process with normal wood-working machinery
- Glue (e.g. white glue) is applied onto the wooden materials, as the fleece absorbs moisture and glue stains may appear on the front if glue is applied to the fleece
- Cover the natural surface with the enclosed separating paper
- Guidelines:

Max. pressing temperature. 60°C Max. pressure 1 kg/cm²

Glue application: approx. 100 g/m² Pressing time: approx. 15 minutes

Pre-trials and tests are recommended

Glue recommendations

As wallpaper: Glutolin ECC extra clear As a compound in wood-working: White glue

Pay attention to

Surface must be clean, dry, weight-bearing, evenly absorbent, smooth, dust-free and neutral in colour. Recently plastered walls must be fully dried. Highly absorbent walls must be prepared with a suitable base.

For sensitive wood-working applications, use a counter-balance (enclosed on request). Symmetrical construction is recommended, which means using the same surface on the front and back side.

Acclimatisation of Organoid natural surfaces:

- Bring product to room temperature before unpacking
- Store product protected from light, at about 20°C and 30-60 % relative humidity.

Storage:

- Rolled goods: hanging system (e.g. paternoster)
- Single panels: horizontal position (e.g. drawer system)

Processing guidelines available at:

www.organoids.com/en/installation-technicalimplementation